



AutoDx-Dx to PIF Converter Trial Version

№	Величина	Обозначение	№	Величина	Обозначение	№	Величина	Обозначение	№	Величина	Обозначение
R1	20k	R1	100k	R61	3k	R101	51k	R141	10k	R181	10k
R2	10k	R2	10k	R62	100k	R102	10k	R142	10k	R182	10k
R3	10k	R3	10k	R63	100k	R103	10k	R143	10k	R183	10k
R4	100k	R4	100k	R64	1k	R104	1k	R144	1k	R184	1k
R5	30k	R5	100k	R65	75k	R105	270k	R145	100k	R185	100k
R6	22k	R6	22k	R66	27k	R106	27k	R146	27k	R186	27k
R7	68k	R7	100k	R67	51k	R107	51k	R147	51k	R187	51k
R8	22k	R8	22k	R68	27k	R108	27k	R148	27k	R188	27k
R9	10k	R9	10k	R69	10k	R109	10k	R149	10k	R189	10k
R10	10k	R10	10k	R70	51k	R110	51k	R150	51k	R190	51k
R11	47k	R11	75k	R71	51k	R111	100k	R151	100k	R191	100k
R12	33k	R12	27k	R72	100k	R112	22k	R152	100k	R192	22k
R13	27k	R13	100k	R73	51k	R113	100k	R153	51k	R193	100k
R14	10k	R14	10k	R74	100k	R114	10k	R154	100k	R194	10k
R15	1M	R15	100k	R75	75k	R115	100k	R155	75k	R195	100k
R16	470k	R16	27k	R76	10k	R116	10k	R156	10k	R196	10k
R17	100k	R17	27k	R77	10k	R117	10k	R157	10k	R197	10k
R18	33k	R18	51k	R78	22k	R118	22k	R158	22k	R198	22k
R19	1M	R19	15k	R79	22k	R119	22k	R159	22k	R199	22k
R20	56k	R20	15k	R80	51k	R120	51k	R160	51k	R200	51k

№	Величина	Обозначение	№	Величина	Обозначение	№	Величина	Обозначение	№	Величина	Обозначение
C1	3-20pF	C1	100pF	C11	0,1M	C21	300pF	C31	0,01M	C41	0,01M
C2	0,01M	C2	0,01M	C12	0,01M	C22	0,01M	C32	0,01M	C42	0,01M
C3	100pF	C3	100pF	C13	100pF	C23	100pF	C33	100pF	C43	100pF
C4	0,01M	C4	0,01M	C14	0,01M	C24	0,01M	C34	0,01M	C44	0,01M
C5	0,01M	C5	0,01M	C15	0,01M	C25	0,01M	C35	0,01M	C45	0,01M
C6	0,01M	C6	0,01M	C16	0,01M	C26	0,01M	C36	0,01M	C46	0,01M
C7	0,01M	C7	0,01M	C17	0,01M	C27	0,01M	C37	0,01M	C47	0,01M
C8	0,01M	C8	0,01M	C18	0,01M	C28	0,01M	C38	0,01M	C48	0,01M
C9	0,01M	C9	0,01M	C19	0,01M	C29	0,01M	C39	0,01M	C49	0,01M
C10	0,01M	C10	0,01M	C20	0,01M	C30	0,01M	C40	0,01M	C50	0,01M

KROT-M DXT-0010 List 1

AutoDWG DWG to PDF Converter Trial Version

Note: Please goto <http://www.autodwg.com> to register the program,
the note and watermark will be removed.